HOT STREAK II JetTruck

EGRESS PLAN



SAFETY HARNESS RELEASE TURN TO RELEASE EITHER DIRECTION

PUSH
ON BOARD FIRE EXTINGUISHER
PUSH TO DEPLOY

EMERGENCY SHUTOFF HANDLE PULL
TO REAR

PRIMARY CONTROLS ALL HANDLES
AFT/TO REAR

SWITCH CONTROL PANEL ALL SWITHCES
PUSHED IN

FUEL TANK LOCATIONS TWO SADDLE TANKS ONE ON EACH SIDE OF TRUCK ONE CENTER TANK LOCATED IN SLEEPER

Hot Streak II JetTuck

A/C Type: JetTruck

Fuel Type / Amount: Diesel/150 Gallons

Number of Soles on Board (SOB): One/Two

Battery Location: 2 - 12 volt sealed batteries

Cockpit Entry Procedures:

1. Climb in through side doors

2. No Cockpit Canopy

JetTruck Shutdown Procedures:

1. All levers on right side of driver swept aft.

2. All toggle switches to left of drivers head and forward of drivers head pushed in

Pilot Restraint System: (5 star, regular seat belt, ect.)

5 -point harness. Twist center buckle counter in either direction to release all

Special Hazards - None

Ejection Seat - None

LOX - None

Smoke - None

Pyro - None

Pilot's Special Needs or Concerns:

None. Would like a JetTruck brief with safety crews after daily brief

Contact Phone Numbers: 660-624-3976